

1. STATUS DISPLAYS (pictograph) Error messages	16. INSTALLATION PLANNING Specifications	
2. SERVICE PROGRAMM	17. INSTALLATION Startup procedures Instructions/Codes	
3. REFERENCE DIAGRAMS	18. MAINTENANCE INSTRUCTIONS Maintenance checklist	
4. GENERAL CIRCUIT DIAGRAM Block diagram	19. ACCESSORIES Scope of delivery Fitting instructions/circuit diagrams/spare parts	
5. SPARE PARTS LIST Spare parts kits - order instructions	20. FITTING INSTRUCTIONS	
6. OPERATION and PROCESS PARAMETERS Codes	21. TECHNICAL INFORMATION Trouble shooting list	
7. ELECTRICAL ASSEMBLIES Plug assignment diagrams Circuit diagrams	22. FLASH INFOS	
8. REPAIR INSTRUCTIONS	23.	
9. FLOW CHART Program versions Differences	24.	
10. TRANSPORT-SYSTEM film (racks) Wet section Dryer	25.	
11. Drives (electrical, mechanical)	Rack drive Circulation pump drive Measuring - rack torques Adjustment - toothed belt drive	26.
12. SOLUTION HEATING SYSTEM Measuring system description Temperature adjustment Heaters/thermal cutouts Replenisher pump/solenoid valves Adjustment - replenishment rates	27.	
13. DRYER Function Dryer distributor board	28.	
14. LEVEL MONITORING Machine tanks Replenisher tanks Disposal tanks	Level sensors Installation Electrical connections	29.
15. POWER SUPPLY Mains circuit Mains/distributor/circuit breaker board	30.	